

iLOQ KEY K10S.3 INSTRUCTIONS FOR USE AND MAINTENANCE

ENG 44066

iLOQ Key K10S.3 Instructions for use and maintenance v.1.0



INSTRUCTIONS FOR USE

To operate the iLOQ cylinder, insert the iLOQ Key entirely into the keyway and turn the key. If the cylinder does not open, remove the key and re-insert it into the cylinder again, this time more slowly.

The electric energy is harvested for operations when the key is inserted into the cylinder. If the movement is too fast, the cylinder is kept in the locked state. Do not use excess force when inserting the key into the cylinder.

MAINTENANCE

The contact wire on the metal part of the key must be clean and smooth. If the contact wire is dirty, wipe it clean using a soft tissue. Replace the key if the contact wire is damaged.



Do not use the iLOQ key for other purposes except those mentioned in these Instructions. Using the iLOQ key for other purposes may damage the key. Do not insert any other item than iLOQ Key into the iLOQ Cylinder. The key is to be kept securely so that only authorized person may have access. In case of losing the Key, blacklisting of the lost Key shall be done with the iLOQ S10 Manager software and the affected locks shall be reprogrammed.

CHANGING THE COLORED CAP

The colored cap can be changed. Remove the cap by turning it 45 degrees counter clockwise with a thumb or with a sharp tool. Lift off the cap and place a new cap in its place. Lock it up by turning the cap 45 degrees clockwise.

Attention. Gray colored cap is not removable.

